

## ACCURIZE LASER TRAINER CARTRIDGE



Advarsel ! Unngå direkte øyeksposering. Laser lys. Oppbevares utilgjengelig for barn.  
Warning! Avoid direct eye exposure. Laser light. Keep out of reach of children.

### First time use and battery replacement

1. Unscrew the back of the laser cartridge
2. First time use, take out the black coverage.
3. For changing battery, take out old batteries and insert new batteries.
4. Screw the cap on all the way, and its ready to use.
5. The cartridge should be very tight in the chamber, so a good advice may be to lubricate some oil on the o-rings before introduction



### Installation and usage :

1. Unload your firearm! Always point in a safe direction.
2. Insert laser trainer cartridge into the chamber of the firearm.
3. Ready your pistol and point it to the target , pull trigger to fire the red laser dot.
4. Remove laser trainer cartridge when finished shooting. With eraser end of a pencil or a cleaning rod (pussestokk) , insert into barrel and gently push laser trainer cartridge out.



